

FIG. 2

FIG. 3

SELECT
PAY INSIDE
OR PAY OUTSIDE

68

ACTION
- SELECT "PAY INSIDE"

FIG. 4

REMOVE NOZZLE
AND PUMP GAS

70

ACTION
- REMOVE NOZZLE
AND PUMP

FIG. 5

WOULD YOU
LIKE TO
HAVE SOME CASH?
IF SO PRESS "YES"

72

ACTION
- NO RESPONSE
- REPLACE NOZZLE

FIG. 6

PLEASE PAY
INSIDE

74

ACTION
- USER PAYS INSIDE

FIG. 7

**SELECT
PAY INSIDE
OR PAY OUTSIDE**

76

ACTION

- USER SELECTS "PAY OUTSIDE"

FIG. 8

**PRESS
1 FOR CREDIT CARD
2 FOR DEBIT CARD
3 FOR STORED VALUE
CARD**

78

ACTION

**- USER SELECTS INPUT
FOR EXAMPLE "1" FOR
CREDIT CARD**

FIG. 9

**PLEASE INSERT
CREDIT CARD IN
CARD READER AND
WITHDRAW QUICKLY**

86

ACTION

**- USER INSERTS CARD
AND WITHDRAWS CARD**

FIG. 10

**REMOVE NOZZLE
AND PUMP GAS**

88

ACTION

- REMOVE NOZZLE AND PUMP

FIG. 11

**WOULD YOU
LIKE TO
HAVE SOME CASH?
IF SO PRESS "YES"**

98

ACTION

- NO RESPONSE
- REPLACE NOZZLE

FIG. 12

**WOULD YOU LIKE
A RECEIPT ?
PRESS
"YES" OR "NO"**

100

ACTION

- USER PRESSES SELECTED KEY
EXAMPLE "YES"

FIG. 13

**RECEIPT IS NOW
PRINTING**

102

ACTION

- PRINTER PRINTS RECEIPT

FIG. 14

**THANK YOU
PLEASE TAKE RECEIPT**

104

ACTION

- USER TAKES RECEIPT

FIG. 15

**PLEASE ENTER YOUR
PIN NUMBER AND
THEN PRESS #
PRESS * TO CLEAR**

92

ACTION

**- USER INPUTS PIN AND
THEN #**

FIG. 16

**PLEASE INSERT
STORED VALUE CARD
INTO READER AS
FAR AS IT WILL GO**

94

ACTION

**- USER INSERTS STORED VALUE
CARD**

FIG. 17

**SORRY, WE ARE
UNABLE TO PROCESS
YOUR TRANSACTION**

96

ACTION

**- MACHINE RETURNS TO FIRST
SCREEN AFTER TIME OUT**

FIG. 18

**PLEASE INPUT AMOUNT
BY PRESSING KEYS
THEN PRESS #
MAXIMUM \$100**

106

ACTION

**- USER INPUTS AMOUNT
AND #**

EXAMPLE \$100 INPUT

FIG. 19

**\$100 FROM
CREDIT CARD
PRESS "YES" TO CONFIRM
"NO" TO INPUT NEW AMOUNT**

108

ACTION

**- CUSTOMER PRESSES
APPROPRIATE BUTTON**

EXAMPLE "YES"

FIG. 20




FIG. 21




FIG. 22




FIG. 23





FIG. 24






FIG. 26

PAY BY
1 CARD
2 CASH

192

ACTION

- USER SELECTS CASH OR CARD
EXAMPLE CASH

FIG. 27

**INSERT BILLS INTO
BILL ACCEPTOR BELOW**

**PRESS "1" TO RETURN TO
FIRST SCREEN**

194

ACTION

- USER INSERTS NOTES INTO
NOTE ACCEPTOR OR RETURNS
TO BEGINNING
EXAMPLE NOTE INPUT

FIG. 28

AVAILABLE CREDIT
\$20.00
**PRESS "1" TO RETURN TO
FIRST SCREEN**
PRESS "2" TO BEGIN PUMPING

196

ACTION

- USER INSERTS MORE NOTES
OR PRESSES OTHER OPTIONS
EXAMPLE USER PRESSES "2"

FIG. 29

**REMOVE NOZZLE
AND PUMP GAS**

198

ACTION

- USER REMOVES NOZZLE
AND PUMPS
- PUMP STOPS WHEN AVAILABLE
CREDIT IS REACHED OR
CUSTOMER SHUTS OFF

FIG. 30

**YOUR AVAILABLE
CREDIT IS GREATER
THAN YOUR CHARGE
A CASH VOUCHER FOR
THE DIFFERENCE IS
PRINTING**

200

ACTION

**- MACHINE PRINTS VOUCHER
FOR DIFFERENCE**

FIG. 31

**PLEASE PRESENT
VOUCHER INSIDE
TO RECEIVE YOUR
CASH**

202




FIG. 32




FIG. 33




FIG. 34




FIG. 35




FIG. 36




FIG. 37





FIG. 38








FIG. 40






3 - Select transaction —————→

212 ↗

FIG. 42



212

FIG. 43




FIG. 44





FIG. 45



6 - Thank You

FIG. 46






FIG. 48




FIG. 49




FIG. 50




FIG. 51




FIG. 52





FIG. 53


FIG. 54






378

FIG. 55





**"Okay - I have your
order as**

Is that Right?"

**Yes / Yeah / Right / Correct
No / Nope / Nah / Incorrect**

**"I'm Sorry I Must
Have Messed Up- Please
Give Me Your Order
Again."**

**"So Your Total Will
Be \$____. How
Would You Like To
Pay? Cash Or Card
(Or Would You Like to
Cash a Check)"**

FIG. 57




FIG. 58




FIG. 59